

Rate Update Instructions

Follow the steps on the other side of this page to install your new Rate Card. If you encounter unusual prompts or errors, restart the install beginning with Step 1 on that page. This normally solves most problems.

If you have additional questions, visit our web site at www.pb.com/ratesandupdates. You can also get personalized information by logging in to My Account. For more details on the carrier changes, contact your local carrier representative.

IMPORTANT: Install the new Rate Card only when you are ready to use the new rates on the effective date. Once you put the new Rate Card into your machine, the old rates will no longer be available in most cases.

Part Number Update

The part number you usually receive may have changed. If you did not receive your usual part number please refer to the notes below.

- Rate Card Part numbers N582002 and N582003 have been replaced with part number N582000.
- Rate Card Part numbers N982913, N982914 and N982915 have been replaced with part number N982912.

If you cannot find your answer at www.pb.com/ratesandupdates, call our Rates and Update Center at 1-800-962-4088 Monday through Friday between 8:00 AM and 8:00 PM Eastern time. When you call, please have your Product Code and Serial Number available.

Product Codes covered by this update: **N300, N30R, 3K00, 3K0R, N400, N40R, 4K00, 4K0R, N500, N50R, 5K00, 5K0R, N600, N60R, 6K00, 6K0R, N700, N70R, 7K00, 7K0R, N900, N90R, 9K00, 9K0R, N601, N610, N61R, 6K01, 6K1R, 6K1S, 6K10, N701, N710, N71R, 7K01, 7K1R, 7K1S, 7K10, N901, N910, N91R, 9K01, 9K1R, 9K1S, 9K10, N91S, N9RA**

Rate Card Part Numbers covered by this update: **N382000, N482000, N582000, N982912.**

